


# Network Speed Dome & PTZ Camera Installation Guide




#### Contents




#### 2 Dimensions



# 3 Warning/Safety Precaution



### 4 Interface




9	10	Baud Rate 9600bps 4800bps		
OFF	OFF			
ON	OFF			
OFF	ON	2400bps		
ON	ON	1200bpc		


11	12	HD/SD Video Mode
OFF	OFF	HD
ON	OFF	/
OFF	ON	/
ON	ON	SD


Address	1	2	3	4	5	6	7	8
0	OFF							
1	ON	OFF						
2	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
3	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
4	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
5	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
6	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
7	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
8	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
254	OFF	ON						
255	ON							

# 6 Assembly Instruction










# 6 Alternate Mounting Setups





#### Copyright Information

#### Statement

AVYCON all rights reserved.

Without our official written permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means (electronic, mechanical, printing, recording or other possible means) or for the propagation of goods any commercial, profitable purposes.

AWYCON® is the registered trademark of Big Cart Corporation Company in California, United States. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide.

All statements, information, etc. are not consitute anyform of guarantee